



## *Handlebars for the long haul*

### **2006-2008 Honda ST1300 Police Version** Installation Instructions - Part # HC0303P/GP (Page 1)

1/2" taller \* 2 1/2" more rearward \* Improved Angles

---

**WARNING: IMPROPER INSTALLATION COULD RESULT IN SERIOUS INJURY OR DEATH.  
HAVE A QUALIFIED MECHANIC INSTALL YOUR HELI BARS.**

Note: If you are attempting to install this special adapter on a standard ST1300 be aware that the police version has a different throttle housing and cables. This adapter will not fit a standard ST1300.

- 1.) Remove both left and right control housing wire looms from the strap that attaches them to the outsides of the handlebar riser beams.
- 2.) Remove center plastic cover located between the handlebars.
- 3.) Remove the two cap head screws and bolt from each bar. Remove both stock bar spacers. They will not be re-used.
- 4.) Remove the factory bar mount. The top hex head is 12mm and the bottom nut is 14mm. Use an offset 14mm hex wrench to hold the nut and loosen from the top 12mm head. There is a large washer on top of the lower nut. Repeat for the left bolt.
- 5.) Install the Heli Billet Bar Adapter. It will only fit one way. Move the front wheel so it's facing straight forward. First remove the billet center cover by removing the two outer cap head screws. Remember to place the large washer on the bottom before the nut is attached. This requires both hands, one to hold the washer in place and the other to start the nut. Torque both bolts to 14 ft. lbs.
- 6.) Install the bars onto the adapter. Install the two cap head screws and one button head screw through the bar base and into the adapter. The two button head screws (supplied) must be placed in the two inside mounting holes closest together. They will be located under the billet center cover. Be careful not to cross thread the bolts. Tighten all three pieces to 12 ft. lbs. It may be necessary to pull up on the cables and hydraulic lines to gain a bit of extra slack. They will naturally settle back into a new position after install is complete and the bars have been rotated several times lock to lock.

(Continued)

**2006-2008 Honda ST1300 Police Version**  
**Installation Instructions - Part # HC0303P/GP (Page 2)**

7.) Reinstall the center cover, adjust a bit for the best fit and torque the two 6mm cap head screws to 7 ft. lbs.

Double check all controls for tightness. Start machine and in neutral, go lock to lock and make sure the throttle cables move freely and that the RPM's do not increase.

**HC0303G** – Installing Ram Mount Ball: Use care when threading , over-tightening will damage adapter and void warranty.

**!! CAUTION!! BARS MUST BE TORQUED TO SPECIFIED VALUES. THEY MUST NOT BE OVERTORQUED.  
OVERTIGHTENED HARDWARE CAN LOSE INTEGRITY.**

For questions regarding installation please call 1-800-859-4642.

**HELI MODIFIED, INC. ASSUMES NO LIABILITY FOR ANY INJURY OR LOSS OF PROPERTY WHICH MAY RESULT IN  
IMPROPER USE OF ANY HELI BARS.**

**Heli Modified, Inc. PO Box 638 - 20 Industrial Way - Cornish, Maine 04020**  
**[www.helibars.com](http://www.helibars.com)**

January 31, 2008